Wall fitting instructions

-SOCKET-
BOX
POP UP SOCKETS



Switch to be tapped to cabinet lid before work surface has been installed and secured with duct tape to avoid damage, switch connector should be accessible from inside of cabinet for connecting once socket box has been securely fixed. The connector and switch tail is colour coded for easy connection.

WARNING DO NOT BEND OR KINK SWITCH TAIL

www.socketbox.co.uk